
BIFOLD DOOR




INSTALLATION GUIDE

Size	Product code	Adjustment	Opening space
700	A1200A0	650-690	400
760	A1200B0	710-750	460
800	A1200C0	750-790	500
900	A1200D0	850-890	600


ATTENTION


If you install the product in a way that differs from this manual this will void all guarantees. Before installation check that the product meets all your requirements and is not damaged. By proceeding with installation, You accept the condition of the product. The wall plugs supplied with the installation kit are for use in solid walls. Hollow or 'stud partition' walls will require alternative fixings. Please consult your local hardware supplier for the correct type.




NO.	Qty	Part No.	
1	2	A02S0020	
2	6	2SY51	
3	6	2SP12	
4	1	A	
5	2	2SS020 L/R	
6	4	2SQF2&2SQF3	

NO.	Qty	Part No.	
7	4	2SS020A	
8	2	2SS018 L/R	
9	1	В	
10	1	A12S0023	
11	6	2SY50	
12	12	C070	







Determine your step in from the edge of the tray. Measure your x and y dimension. Your measurements must fall within the below table of adjustments marked as X.

Level your wall profiles and mark the points of fixing.

